

Shower Mixer Installation Guide

Technical Specifications:

Operating Pressure:

Min: 55kPa/0.55bar

Max: 500kPa/5bar*

Operating Temperature:

Hot: Max 80°C*


Cold: Min 5°C

Inlet Connections:

All ½" BSP

USE PARALLEL FITTINGS ONLY

** Regional specific regulations apply.
Please refer to your warranty statement
at www.methven.com*



Care and Cleaning:

Never use abrasives or abrasive cleaning agents to clean this product. Clean regularly with contamination free warm soapy water and a damp soft cloth.

Methven warrants this product against manufacturing defects and that it is suitable for use under the general operating conditions specified in this instruction sheet. However, regional regulations apply and may affect your warranty. Please refer to www.methven.com or call customer service for full details.

New Zealand
0800 804 222

Australia
1300 638 483

UK
0800 195 1602

433822


ISSUE A

echo
BY METHVEN

IMPORTANT: Please read all of the instructions before installation.

General:

- Methven recommends this product is installed by a licensed plumber in compliance with all relevant regional regulations.
- Do not hydrostatic test the installation with this mixer installed. Damage to the ceramic cartridge may occur.
- All pipe work must be thoroughly flushed prior to the installation of the mixer.
- Do not remove the ceramic cartridge from the mixer when installing.
- After installation all connections must be checked for leaks.
- All outlets used primarily for personal hygiene shall deliver water at a safe temperature as per regional regulations.
- This mixer is not recommended for use in uncontrolled heating systems such as wet-backs or solar heating units unless a suitable tempering valve is fitted.
- It is the responsibility of the installer to ensure a waterproof seal is achieved between the product and mounting surface. If in doubt about the quality of the seal, remove the product and reinstall.



IMPORTANT: Before you begin, turn off the water supply.

Installation:


Step 1

- Leave plastic cover in place during the installation. Plastic cover shape may vary depending on product.

Unequal pressure installation only:


Attach the restrictor nipple to the cold inlet of the mixer body. Ensure a proper seal and allow for access to the adjustment screw from the front.

- Installation depth, **ID= 58 ± 10mm**. This is defined as the distance between the mounting surface and the finished wall surface.
- Secure the mixer body on to the supporting timber ensuring that it is oriented square and vertical.



Step 2

- Flush all pipe-work thoroughly prior to the next step.
- Connect mixer body to hot and cold supplies and outlet ensuring a good seal at each joint.
- Check for leaks prior to closing the wall cavity.




Step 3

- Wall lining should be cut or finished to observe the dimension of the hole provided in the diagram on the right.

Unequal pressure installation:

Ensure the adjustment screw on the restrictor nipple is unobstructed and can be accessed from the front.



Step 4

- Remove plastic cover.
- **Unequal pressure installation:** Push the handle onto the cartridge lever, adjust it to a vertical position and open fully. Adjust the restrictor nipple screw to achieve a good showering temperature at the outlet (e.g. 38°C). Remove the handle before next step.
- Wet the faceplate body seal.
- Apply silicone to the faceplate to create a seal with the finished wall surface. Ensure the silicone does not block the notch in the faceplate.
- Slide faceplate onto mixer body, and position with notch towards the bottom.
- Push handle on to cartridge lever. Tighten grub screw firmly with hex key provided and cap the grub screw hole with the chrome cover.

