Outlet Stream shaper Position studs O-ring (remove if fitting at right angle base ring) to outlet Mounting gasket Mounting plate Mounting stud Mounting nut Flexible inlet hose: cold hot

"In situ" testing

The maximum working pressure of the ceramic cartridge is 1000kPa. Do not hydrostatic test the installation with this mixer installed. Damage to the ceramic cartridge may occur, voiding our warranty.

Kaha Swivel Basin Mixer

01-7003




Illustration may not reflect actual product shape.

Installation Guide

IMPORTANT

Please read all of the instructions before installation

Use of this product in non-domestic applications voids warranty.

All pipe work must be thoroughly flushed prior to the installation of the mixer.

NEFA inline filters must be installed on both hot and cold supplies.

Do not remove the ceramic cartridge from the mixer when installing.

Damage caused by hydrostatic testing is not covered by our warranty.



JUNE 2011 MA017003





Technical Specifications

Inlet Connections: All ½" BSP
Operating Pressure: 150kPa - 500kPa


Operating Temperatures: Recommended hot water supply 50°C,


maximum 70°C. AS 3500 requires all hot water supplies to any sanitary fitting to be

tempered to 50°C.

Hose Requirements for mixers

The maximum working pressure of the ceramic cartridge is 1000kPa. Do not hydrostatic test the installation with this mixer installed. Damage to the ceramic cartridge may occur.





Installation

- A single 35mm diameter hole is required in the mounting surface. The mounting surface can be a maximum of 40mm thick.
- 2. Screw the threaded studs into the base of the mixer. Insert the O ring into the groove in the bottom of the base ring and fit the base ring to the bottom of the mixer.
 - NOTE: Base ring use is optional and should be used when required to ensure a seal is achieved between the tap and basin. If fitting base ring please remove the o-ring from the base of the tap body.
- Insert the flexible hoses through the hole in the mounting surface (from the underside) and screw them into the base of the mixer.
- 4. Feed the threaded studs through the hole in the mounting surface. Fit the mounting gasket and mounting plate onto the threaded rods.
- 5. Ensure the 2 threaded studs are located at the rear of the mixer at right angle to the outlet.
- 6. Tighten the mounting nuts to secure the mixer in place.
- 7. Connect the flexible hoses to the hot and cold supplies (hot on the left, cold on the right). It is a condition of our warranty that the filter washers as supplied be fitted at this connection.

THE METHVEN GUARANTEE